

# ASSEMBLY INSTRUCTIONS FOR STUDIO SPARES 449290 TRIPLE ROD TRIANGLE BASE MONITOR STAND

## PARTS LIST

- 1x Allen Key Wrench
- 3x M8 x 20mm Bolts
- 3x M8 x 50mm bolts
- 3x M8 washers for M8 x50mm bolts
- 3x M8 spikes
- 3x M8 nuts for spikes
- 3x Plastic feet
- 1x Top Plate
- 1x Triangular Base
- 3x 830mm legs



## Putting it together

- Stand the triangular Base on it's side and plug in one of the three legs into the slots in the base.
- Secure this with an M8 50mm bolt and a washer.
- Tighten bolt with the allen key
- Repeat for the other two legs



## Plastic Feet

- Screw either three plastic feet or three spikes into the three threaded holes on the underside of the base

## The spike

- Turn the spike until it is at the desired position and fit the nut to lock the spike into place.



- Stand the assembly up and using the 3x M8 x 20mm bolts secure the top plate to the legs. Tighten bolts.

