

LITTLE DEVIL COLORED BOOST

IMPORTANT - READ BEFORE USING


The Little Devil Colored Boost pedal runs on any one 9 VOLT "BOSS" style power supply or 9 VOLT battery.

Only use a supply with the following polarity symbol.







BATTERY REPLACEMENT

To open any Chandler Limited pedal, remove the four black screws on the sides. **DO NOT** remove screws from the top of pedal.



BATTERIES NOT INCLUDED



RECALL



SUGGESTED SETTINGS

AGGRESSIVE

IN YOUR FACE



FUZZ

JUST A TOUCH

